



NOW BREW

Espresso Machine Cleaning Powder

For Use With:
Automatic Espresso Machines

Always follow the manufacturer's cleaning and disassembly instructions. Mix ratios can be adjusted if a stronger solution is required. For your comfort and safety, wear rubber gloves and eye protection when using this product.

DIRECTIONS FOR USE

Backflush Instructions for Each Group Head

1. Insert blind filter with ½ teaspoon (3g) of Espresso Machine Cleaning Powder in portafilter.
2. Run brew cycle for 10 seconds, pause 10 seconds. Repeat 5 times.
3. Remove portafilter. Activate brew cycle and rinse portafilter under group head water. Stop cycle.
4. Reinsert portafilter. Run brew cycle for 10 seconds, pause 10 seconds. Repeat 5 times to rinse.
5. Make and discard one cup of espresso to ensure no residue remains.

This product carries a triple zero Health and Safety rating. For more information, please refer to the safety data sheet found at nowbrew.com/safetydatasheet.



For questions about Espresso Machine Cleaning Tablets please contact the manufacturer directly at:
800.533.0027 | nowbrew@nationalchemicals.com